Equilibrium Equations:

Two-Dimensional

- Archimedes Lever
- · Newton's First Law
- Loading Types
- End Conditions
- Free Body Diagrams
- End Reactions




University of Michigan, TCAUP Structures I Slide 1 of 13

Archimedes of Syracuse (287 BC – 212 BC)

Greek mathematician, engineer, inventor


- The Lever (On the Equilibrium of Planes)
- The Screw (water pump)
- Greek Fire (to burn boats)
- Archimedes' Principle (density measure)
- Block and Tackle (for lifting on boats)
- Catapult
- Odometer
- Mathematical observations on circles and spheres







by Domenico-Fetti




Archimedes Lever

Two forces will balance at distances reciprocally proportional to their magnitudes.

$$\mathbf{F}_1 \times \mathbf{a} = \mathbf{F}_2 \times \mathbf{b}$$

$$\mathbf{F}_1 = \mathbf{F}_2 \, \frac{\mathbf{b}}{\mathbf{a}}$$





University of Michigan, TCAUP Structures I Slide 3 of 13


Archimedes Lever


Two forces will balance at distances reciprocally proportional to their magnitudes.

Applied to beam end reactions:

$$\mathbf{R}_1 = \mathbf{P} \frac{\mathbf{b}}{\mathbf{L}}$$

$$\mathbf{R}_2 = \mathbf{P} \frac{\mathbf{a}}{\mathbf{L}}$$






Newton's First Law

An object at rest will remain at rest unless acted upon by an outside, external net force.

$$\sum \mathbf{F}_{x} = 0 \quad \sum \mathbf{F}_{y} = 0 \quad \sum \mathbf{M} = 0$$

Horizontal Equilibrium

$$\sum \mathbf{F}_{x} = 0$$





Vertical Equilibrium

$$\sum \mathbf{F}_y = 0 = \mathbf{R}_1 + \mathbf{R}_2 - \mathbf{P}$$

$$\mathbf{R}_1 + \mathbf{R}_2 = \mathbf{P}$$

Rotational Equilibrium

$$\sum \mathbf{M}_1 = 0 = \mathbf{P}\mathbf{a} - \mathbf{R}_2 \mathbf{L}$$

$$\mathbf{R}_2 = \frac{\mathbf{P}\mathbf{a}}{\mathbf{L}}$$

$$\mathbf{R}_2 = \frac{\mathbf{Pa}}{\mathbf{L}}$$

University of Michigan, TCAUP


Structures I

Slide 5 of 13

Slide 6 of 13

Quiz

Find the end reactions R1 and R2



Support Conditions


Roller

Fixed in Fx

Hinge

Fixed in Fx

Fixed in Fy




Fixed

Fixed in Fx

Fixed in Fy

Fixed in Mz



University of Michigan, TCAUP

Structures I

Slide 7 of 13


Slide 8 of 13

Free Body Diagrams

A Free Body Diagram (FBD) is a part cut from a larger force system.


When the FBD is cut free, all "exposed" forces are shown

If the complete system is in static equilibrium, then the FBD with forces at the cut will also be in equilibrium



Free Body Diagrams

A Free Body Diagram (FBD) can be used as a step in solving the external forces





University of Michigan, TCAUP Structures I Slide 9 of 13

End Reactions

Example 1

- Label components of reactions. Depending on the support condition, include vertical, horizontal and rotational.
- 2. Convert area loads to point loads through the centroid (balance point) of the area.
- 3. Since there is only one horizontal force, it must equal zero.






End Reactions

Example 1

- 4. Use the summation of moments about A to find R_B .
- 5. Use the summation of moments about B to find R_{Δ} .
- 6. Check calculation by summing vertical forces.



$$\Sigma MeA = 0 = 24(6) + 10(12) - R_B(15)$$
 $R_B(15) = 264$
 $R_B = 17.6^{K} \uparrow$

EMeB = 0 =
$$R_A(15) - 24(9) - 10(3)$$

 $R_A(15) = 246$
 $R_A = 16.4^K +$

University of Michigan, TCAUP


Structures I

Slide 11 of 13

End Reactions

Example 2

- 1. Use the summation of moments about R2 to find R1.
- 2. Use the summation of moments about R2 to find R1.
- 3. Check calculation by summing vertical forces.



$$\Sigma MeR_1 = 4^{\kappa}(2') + 24^{\kappa}(4') + 16^{\kappa}(2') - R2(12') = 0$$


 $R2(12') = 232^{\kappa-1}$
 $R2 = 19.33^{\kappa}$

$$\Sigma F_{\nu} = 24.67^{k} + 19.33^{k} - 4^{k} - 24^{k} - 16^{k} = 0$$

 $\Sigma F_{\nu} = 0$ Vok


End Reactions Example 3

- Label components of reactions.
 You will need one equation for each unknown reaction.
- 2. Write an equation for the summation of horizontal forces.
- 3. Write an equation for the summation of moments.
- 4. Write an equation for the summation of vertical forces.
- 5. It is good practice to write one additional equation to check the results. In this case summation of moments at C also = 0.



$$F_V = \cos 30^{\circ}(2) = 1.732^{k} \downarrow$$

 $F_H = \sin 30^{\circ}(2) = 1.0^{k} \rightarrow$



$$\Sigma M_A = 0$$

 $2(10) + 2(20) + 2(30) - R(40) = 0$
 $R(40) = 120$
 $R = 3$

$$\Sigma F_{V} = 0$$

-1.732(3) + 3 + V = 0
 $V = 2.196^{k} \uparrow$

University of Michigan, TCAUP

Structures I

Slide 13 of 13